

**073206T4BLD**

**BUILDING TECHNICIAN LEVEL 6**

**CON/OS/BUT/CR/10/6**

**Install Building Doors and Windows**

**July/August 2025**



**TVET CURRICULUM DEVELOPMENT, ASSESSMENT AND CERTIFICATION  
COUNCIL (TVET CDACC)**

**PRACTICAL ASSESSMENT**

**Time: 6 HOURS**

**INSTRUCTIONS TO CANDIDATE:**

1. You are required to perform the following tasks
  - i. Fabricate and fix the door frame as per working drawing.
  - ii. Fix the flush door onto the door frame.
  - iii. Apply two coats of wood varnish finishing to the door frame and door.

**N/B:** Use a Varnish: Turpentine = 1:1 ratio

2. You have been provided with the following resources for the practical tasks:

<b>Tool/equipment</b>	<b>Material</b>
-----------------------	-----------------

<ul style="list-style-type: none"><li>• Measuring tape</li><li>• Spirit level</li><li>• Chisel</li><li>• Mason hammer</li><li>• Mason square</li><li>• Claw hammer</li><li>• Paint brush</li></ul>	<ul style="list-style-type: none"><li>• Timber flush door (600mm x 300mm) – With plywood finish</li><li>• 700mm Timber 50 x 50</li><li>• 300mm Timber 50 x 50</li><li>• Butt hinges</li><li>• Sandpaper</li><li>• 3 inch nails</li><li>• 2 inch nails</li><li>• Turpentine</li><li>• Wood Varnish</li><li>• 3 inch steel nails</li><li>• A temporary wall opening of 650mm x 300mm</li></ul>
--	--

easyvet.com

**WORKING DRAWING**

